


STEP 1



Board Information and Configuration

- Ensure the mode switch SW1 is set to 01 (M1=0 and M0=1).
- Ensure the jumper J46 is ON (jumper in place).
- Please note the MAC ID of the board here.
MAC ID: __:__:__:__:__:__:


STEP 2



Connect the Power Connector

- Turn the PC system OFF.
- Connect the PC systems' 12V ATX power supply's available 4-pin disk drive-type power connector to the board (J27).
Warning: Using any other power supply connector other than the 4-pin in-line connector, will result in damage to the PC system and the SP605 board.
- The power switch SW2 should be switched to the ON (down) position.


STEP 5



Boot Fedora 10 Live and Automatically Login

The screens above will appear on Power UP. Wait two to three minutes depending on the system configuration for the PC to boot completely.

STEP 3



Insert SP605 Board into an Empty PCIe Slot

- Identify the PCIe slot on the PC motherboard.
- Insert the SP605 board into the PCI Express slot through the PCIe x1 edge connector.
- Connect the ethernet LAN cable in the RJ-45 slot. Connect the other end to a live ethernet wall socket.
- Disconnect/disable any existing ethernet connections on the PC system.
- On power-up, the PCIe-GbE design programmed on the SPIx4 Flash will be loaded.


STEP 4

Boot PC from CD-ROM

- Configure the PC system to boot from the CD-ROM drive.
- Place the Fedora 10 Live CD into the CD-ROM drive.

For further information, please refer to the Spartan-6 FPGA Connectivity Kit Getting Started Guide for more details.

STEP 7



Driver Compilation and Kernel Module Insertion


- Navigate to the s6_pcie_dma_ddr3_gbe folder.
- Double-click s6_trd_driver_build to build kernel objects.
- Click Run in Terminal to proceed.
- Scroll and check terminal for errors. If no errors, press any key to exit terminal window.
- Double-click s6_trd_driver_insert to insert driver modules.
- Click Run in Terminal to proceed.
- Scroll and check terminal for errors. If no errors, press any key to exit terminal window.

STEP 6

Copy Contents of USB Flash Drive

- The reference design files are provided on the USB flash drive delivered with the kit.
- Insert the USB flash drive into a USB connector of the PC system.
- Wait for the Fedora 10 OS to mount the USB flash. When the flash is mounted, an icon pops up on the desktop.
- Double-click on the USB flash drive icon and copy the s6_pcie_dma_ddr3_gbe folder into the liveuser's home folder/directory.
- To unmount the USB flash, right-click on the USB flash drive icon and select Unmount Volume.


STEP 8



Network Setup I – Configure the Network

Add a new network device: Open the Network Configuration GUI. Select System > Administration > Network.


STEP 9



Network Setup II – Create a New Device

The Devices tab is empty. A new ethernet connection needs to be created: Click the Devices tab. Select New > Create New Ethernet Connection.


STEP 11



Network Setup IV – Assign MAC Address

- Open a terminal by selecting Applications > System Tools > Terminal.
- Navigate and change the directory to s6_pcie_dma_ddr3_gbe.
\$ cd s6_pcie_dma_ddr3_gbe
- Use the ifconfig utility to check the device.
\$ /sbin/ifconfig eth 1
- Use the "setmac_id" script to assign the MAC address that was recorded in Step 1-C. e.g.
\$./setmac_id eth 1 00:01:02:03:04:05
- Retry the ifconfig utility to verify the MAC ID assignment.
\$ /sbin/ifconfig eth 1


STEP 10



Network Setup III – Create a New Ethernet Connection

- Complete the setup process by following the on-screen instructions carefully. This NIC may be detected as the eth1 interface if there is an active ethernet connection. Select eth1.
- Contact your network administrator to confirm the IP address assignment on the network.
- Save changes by selecting File --> Save, click OK to accept the changes.
- The screen above will appear when this step is complete.

STEP 12



Network Setup V – Activate Ethernet Connection

- Open the Network Configuration GUI.
 - Activate the ethernet interface by clicking the Activate button.
- Step 13 continued on the next page.