

# Vivado Design Suite Properties Reference Guide

UG912 (v2012.2) September 4, 2012



© Copyright 2012 Xilinx

## Notice of Disclaimer



The information disclosed to you hereunder (the "Materials") is provided solely for the selection and use of Xilinx products. To the maximum extent permitted by applicable law: (1) Materials are made available "AS IS" and with all faults, Xilinx hereby DISCLAIMS ALL WARRANTIES AND CONDITIONS, EXPRESS, IMPLIED, OR STATUTORY, INCLUDING BUT NOT LIMITED TO WARRANTIES OF MERCHANTABILITY, NON-INFRINGEMENT, OR FITNESS FOR ANY PARTICULAR PURPOSE; and (2) Xilinx shall not be liable (whether in contract or tort, including negligence, or under any other theory of liability) for any loss or damage of any kind or nature related to, arising under, or in connection with, the Materials (including your use of the Materials), including for any direct, indirect, special, incidental, or consequential loss or damage (including loss of data, profits, goodwill, or any type of loss or damage suffered as a result of any action brought by a third party) even if such damage or loss was reasonably foreseeable or Xilinx had been advised of the possibility of the same. Xilinx assumes no obligation to correct any errors contained in the Materials or to notify you of updates to the Materials or to product specifications. You may not reproduce, modify, distribute, or publicly display the Materials without prior written consent. Certain products are subject to the terms and conditions of the Limited Warranties which can be viewed at <http://www.xilinx.com/warranty.htm>; IP cores can be subject to warranty and support terms contained in a license issued to you by Xilinx. Xilinx products are not designed or intended to be fail-safe or for use in any application requiring fail-safe performance; you assume sole risk and liability for use of Xilinx products in Critical Applications: <http://www.xilinx.com/warranty.htm#critapps>.

©Copyright 2012 Xilinx, Inc. Xilinx, the Xilinx logo, Artix, ISE, Kintex, Spartan, Virtex, Vivado, Zynq, and other designated brands included herein are trademarks of Xilinx in the United States and other countries. All other trademarks are the property of their respective owners.

---

## Revision History

The following table shows the revision history for this document.

Date	Version	Revision
09/04/12	2012.2	Initial Xilinx release.



## Table of Contents

Introduction .....	5
About This Guide .....	5
Copying Syntax and Coding Examples from PDF Documents.....	5
Vivado Design Suite Properties.....	6
Properties Information.....	6
Properties Included .....	6
ASYNC_REG .....	8
BEL .....	10
CLOCK_DEDICATED_ROUTE.....	12
COMPATIBLE_CONFIG_MODES .....	14
DCI_CASCADE.....	16
DIFF_TERM.....	18
DONT_TOUCH.....	21
DRIVE.....	23
HIODELAY_GROUP .....	27
HLUTNM.....	30
IN_TERM .....	34
INTERNAL_VREF.....	36
IOB.....	38
IODELAY_GROUP.....	40
IOSTANDARD .....	43
KEEP_HIERARCHY.....	47
LOC.....	49
LUTNM .....	51
MARK_DEBUG.....	55
PACKAGE_PIN.....	57

© Copyright 2012 Xilinx

PROHIBIT .....	59
SLEW .....	60
VCCAUX_IO .....	63
Additional Resources .....	65
Xilinx Resources .....	65
Solution Centers .....	65
References .....	65

## Introduction

---

### About This Guide

This Guide discusses the properties available for the Xilinx® Vivado™ Design Suite. It consists of the following:

- Chapter 1, this Introduction.
- Chapter 2, [Vivado Design Suite Properties](#), which contains a list of the Vivado properties, including, for each property, a description, supported architectures, applicable elements, values, syntax examples (Verilog, VHDL, and XDC), and affected steps in the design.
- Appendix A, [Additional Resources](#), which contains references to other helpful resources and documents available on the Xilinx Support Website.

---

### Copying Syntax and Coding Examples from PDF Documents

This guide gives numerous syntax and coding examples to assist you in inserting properties into your code. Problems may arise if you copy those examples directly from the PDF document into your code.

- PDF documents insert end of line markers into examples that wrap from line to line. These markers cause errors in your code.
- Copying examples that span more than one page carries extraneous header and footer information along with the example. This information causes errors in your code.

To avoid these problems, edit the example in an ASCII text editor to remove any unnecessary markers or information, then paste it into your code.

**Note** You may skip this process for short examples that do not wrap from line to line.

## Vivado Design Suite Properties

---

### Properties Information

This chapter provides information about Xilinx<sup>®</sup> Vivado<sup>™</sup> Design Suite properties. Each property contains, where applicable:

- A description of the property, including its primary uses.
- A list of the architectures which that property supports.
- The applicable elements for the property.
- The values that can be used with the property.
- Syntax examples, including examples for Verilog, VHDL, and XDC.
- A list of the affected steps in the design for the property.
- Cross references to other related properties.

---

### Properties Included

The properties discussed in this guide include:

- [ASYNC\\_REG](#)
- [BEL](#)
- [CLOCK\\_DEDICATED\\_ROUTE](#)
- [COMPATIBLE\\_CONFIG\\_MODES](#)
- [DCI\\_CASCADE](#)
- [DIFF\\_TERM](#)
- [DONT\\_TOUCH](#)
- [DRIVE](#)
- [HIODELAY\\_GROUP](#)
- [HLUTNM](#)

© Copyright 2012 Xilinx

- IN\_TERM
- INTERNAL\_VREF
- IOB
- IODELAY\_GROUP
- IOSTANDARD
- KEEP\_HIERARCHY
- LOC
- LUTNM
- MARK\_DEBUG
- PACKAGE\_PIN
- PROHIBIT
- SLEW
- VCCAUX\_IO

---

## ASYNC\_REG

ASYNC\_REG specifies that a register can receive asynchronous data on the D input pin relative to its source clock, or that it is a synchronizing register within a synchronization chain.

Specifying ASYNC\_REG affects optimization, implementation, and reporting to report and improve Mean Time Before Failure (MTBF) for registers that may go metastable in the design.

### Architecture Support

All architectures

### Applicable Elements

Cells (get\_cells)


- Registers (FD, FDCE, FDPE, FDRE, FDSE)

### Values

- FALSE (default)  
Register is fully synchronous.
- TRUE  
Register accepts asynchronous input.

### Syntax and Syntax Examples

---

 **IMPORTANT:** Before copying syntax or coding examples from this PDF document for insertion into your code, see [Copying Syntax and Coding Examples from PDF Documents](#) in the Introduction to this guide.

---

#### Verilog Syntax

Place the Verilog attribute immediately before the instantiation or reg declaration of a register in the design:

```
(* ASYNC_REG = "{TRUE|FALSE}" *)
```

#### Verilog Syntax Example

```
// Designates sync_regs as receiving asynchronous data
(* ASYNC_REG = "TRUE" *) reg [2:0] sync_regs;
```



## VHDL Syntax

Declare the VHDL attribute as follows:

```
attribute ASYNC_REG : string;
```

Specify the VHDL attribute as follows:

```
attribute ASYNC_REG of name: label is "{TRUE|FALSE}";
```

*Where*

- `name` is either the instance name of an instantiated register or the declared signal that will be inferred to a register.

## VHDL Syntax Example

```
attribute ASYNC_REG : string;
signal sync_regs : std_logic_vector(2 downto 1);
-- Designates sync_regs as receiving asynchronous data
attribute ASYNC_REG of sync_regs: label is "TRUE";
```

## XDC Syntax

```
set_property ASYNC_REG value [get_cells instance_name]
```

*Where*

- `instance_name` is a register instances in the design.

## XDC Syntax Example

```
# Designates sync_regs as receiving asynchronous data
set_property ASYNC_REG TRUE [get_cells sync_regs*]
```

**Note** When this property is set in both HDL code and in XDC, the XDC property takes precedence.

## Affected Steps in the Design

- `synth_design`
- `place_design`
- `route_design`
- `phys_opt_design`
- `power_opt_design`
- `drc`
- `write_verilog`

---

## BEL

BEL specifies a specific placement within a Slice for a register or LUT.

BEL is generally used with an associated LOC property to specify the exact placement of a register or LUT.

## Architecture Support

All architectures

## Applicable Elements

Cells (get\_cells)

- Registers (FD, FDCE, FDPE, FDRE, FDSE)
- LUTs (LUT1, LUT2, LUT3, LUT4, LUT5, LUT6, LUT6\_2)
- SRLs (SRL16E, SRLC32E)
- LUTRAMs (RAM32X1D, RAM32X1S, RAM64X1S)

## Values

BEL site name

## Syntax and Syntax Examples



**IMPORTANT:** Before copying syntax or coding examples from this PDF document for insertion into your code, see [Copying Syntax and Coding Examples from PDF Documents](#) in the Introduction to this guide.

---

## Verilog Syntax

Place the Verilog attribute immediately before the instantiation of a LUT or register in the design.

Alternative

The Verilog attribute can be placed before the reg declaration of an inferred register, SRL, or LUTRAM in the design:

```
(* BEL = "site_name" *)
```

### Verilog Syntax Example

```
// Designates placed_reg to be placed in FF site A5FF
(* BEL = "A5FF" *) reg placed_reg;
```

## VHDL Syntax

Declare the VHDL attribute as follows:

```
attribute BEL : string;
```

For an instantiated instance, specify the VHDL attribute as follows:

```
attribute BEL of instance_name : label is "site_name";
```

*Where*

- `instance_name` is the instance name of an instantiated register/LUT/SRL/LUTRAM.

### VHDL Syntax Example

```
-- Designates instantiated register instance placed_reg to be placed in FF site A5FF
attribute BEL of placed_reg : label is "A5FF";
```

For an inferred instance, specify the VHDL attribute as follows:

```
attribute BEL of signal_name : signal is "site_name";
```

*Where*

- `signal_name` is the signal name of an inferred register/LUT/SRL/LUTRAM.

### VHDL Syntax Example

```
-- Designates instantiated register instance placed_reg to be placed in FF site A5FF
attribute BEL of placed_reg : signal is "A5FF";
```

## XDC Syntax

```
set_property BEL site_name [get_cells instance_name]
```

*Where*

- `instance_name` is a register, LUT, SRL, or LUTRAM instance in the design.

### XDC Syntax Example

```
# Designates placed_reg to be placed in FF site A5FF
set_property BEL A5FF [get_cells placed_reg]
```

**Note** When this property is set in both HDL code and in XDC, the XDC property takes precedence.

## Affected Steps in the Design

- Design Floorplanning
- `place_design`

## See Also

LOC

---

## CLOCK\_DEDICATED\_ROUTE

CLOCK\_DEDICATED\_ROUTE provides a means to demote a clock placement DRC from an error to a warning when a clock source is placed in a sub-optimal location compared to its load clock buffer.

Setting CLOCK\_DEDICATED\_ROUTE to **False** may result in sub-optimal clock delays resulting in potential timing and other issues.

### Architecture Support

All architectures

### Applicable Elements

Nets (get\_nets)

- Net connected to the input of a global clock buffer (BUFG, BUFGCE, BUFGMUX, BUGCTRL)

### Values

- TRUE
- FALSE
- BACKBONE

### Syntax and Syntax Examples



**IMPORTANT:** Before copying syntax or coding examples from this PDF document for insertion into your code, see [Copying Syntax and Coding Examples from PDF Documents](#) in the Introduction to this guide.

---

#### Verilog Syntax

Not applicable

#### VHDL Syntax

Not applicable

#### XDC Syntax

```
set_property CLOCK_DEDICATED_ROUTE value [get_nets net_name]
```

### Where

- `net_name` is the signal name connected to the input of a global clock buffer.

### XDC Syntax Example

```
# Designates clk_net to have relaxed clock placement rules  
set_property CLOCK_DEDICATED_ROUTE FALSE [get_nets clk_net]
```

### Affected Steps in the Design

- `place_design`
- DRC

---

## COMPATIBLE\_CONFIG\_MODES

COMPATIBLE\_CONFIG\_MODES communicates which configuration mode to use for pin allocations and proper DRC messaging.

### Architecture Support

All architectures

### Applicable Elements

Design (current\_design)

### Values

- Slave Serial
- Slave Serial Mode
- Master Serial
- Master Serial Mode
- Slave SelectMap x8
- Slave SelectMAP Mode, 8-bit width
- Master SelectMap x8
- Master SelectMAP Mode , 8-bit width
- JTAG/Boundary Scan (default)
- Boundary Scan Mode
- Master SelectMap x16
- Master SelectMAP Mode, 16-bit width
- Slave SelectMap x32
- Slave SelectMAP Mode, 32-bit width
- Slave SelectMap x16
- Slave SelectMAP Mode, 16-bit width
- Master SPI x1
- Serial Peripheral Interface, 1-bit width
- Master SPI x2
- Serial Peripheral Interface, 2-bit width

© Copyright 2012 Xilinx

- Master SPI x4
- Serial Peripheral Interface, 4-bit width
- Master BPI-Up x8
- Byte Peripheral Interface (Parallel NOR), 8-bit width
- Master BPI-Up x16
- Byte Peripheral Interface (Parallel NOR), 8-bit width

## Syntax and Syntax Examples



**IMPORTANT:** Before copying syntax or coding examples from this PDF document for insertion into your code, see [Copying Syntax and Coding Examples from PDF Documents](#) in the Introduction to this guide.

### Verilog Syntax

Not applicable

### VHDL Syntax

Not applicable

### XDC Syntax

```
set_property COMPATIBLE_CONFIG_MODES {value(s)} [current_design]
```

**Note** More than one configuration mode value can be supplied.

### XDC Syntax Example

```
# Specify using Configuration Mode Serial Peripheral Interface, 4-bit width
set_property COMPATIBLE_CONFIG_MODES {{Master SPI x4}} [current_design]
```

## Affected Steps in the Design

- I/O Planning
- place\_design
- DRC

---

## DCI\_CASCADE

DCI\_CASCADE specifies which adjacent banks use the DCI Cascade feature, thereby sharing reference resistors with a master bank.

DCI\_CASCADE specifies which bank is the master bank and all associated slave banks for this feature.

### Architecture Support

- Kintex™-7 devices
- Virtex®-7 devices
- Larger Zynq™ devices (XCZ030 and XC7Z045)

### Applicable Elements

- I/O Bank (get\_iobanks)  
High Performance (HP) bank type

### Values

Valid High Performance (HP) bank numbers

### Syntax and Syntax Examples



**IMPORTANT:** Before copying syntax or coding examples from this PDF document for insertion into your code, see [Copying Syntax and Coding Examples from PDF Documents](#) in the Introduction to this guide.

---

#### Verilog Syntax

Not applicable

#### VHDL Syntax

Not applicable

#### XDC Syntax

```
set_property DCI_CASCADE {slave_banks} [get_iobanks master_bank]
```



### Where

- `slave_banks` is a list of the bank numbers of the slave banks.
- `master_bank` is the bank number of the designated master bank.

### XDC Syntax Example

```
# Designate Bank 14 as a master DCI Cascade bank and Banks 15 and 16 as its slaves
set_property DCI_CASCADE {15 16} [get_iobanks 14]
```

## Affected Steps in the Design

- I/O planning
- `place_design`
- `drc`
- `write_bitstream`
- `report_power`

## See Also

DCI\_VALUE

---

## DIFF\_TERM

DIFF\_TERM specifies differential termination use on differential input and bi-directional buffers.

### Architecture Support

All architectures

### Applicable Elements

- Ports (get\_ports)  
Input or bi-directional ports connected to a differential input buffer
- Cells (get\_cells)  
Differential input or bi-directional buffer (all IBUFDS and IOBUFDS variants)

### Values

- FALSE (default)  
Differential termination is disabled.
- TRUE  
Differential termination is enabled.

### Syntax and Syntax Examples



**IMPORTANT:** Before copying syntax or coding examples from this PDF document for insertion into your code, see [Copying Syntax and Coding Examples from PDF Documents](#) in the Introduction to this guide.

---

### Verilog Syntax

DIFF\_TERM can be set within the design by assigning the DIFF\_TERM parameter on the instantiated differential buffer in the design.



**RECOMMENDED:** Use the instantiation template from the Language Templates or the *7 Series Libraries Guide for HDL Designs (UG768)* to specify the proper syntax.

---

## Verilog Syntax Example

The following example enables differential termination on the IBUFDS instance named `clk_ibufds`.

```
// IBUFDS: Differential Input Buffer
//      Virtex-7
// Xilinx HDL Language Template, version 2012.2
IBUFDS #(
    .DIFF_TERM("TRUE"),          // Differential Termination
    .IBUF_LOW_PWR("TRUE"),      // Low power="TRUE", Highest performance="FALSE"
    .IOSTANDARD("DEFAULT")     // Specify the input I/O standard
) clk_ibufds (
    .O(clk),                    // Buffer output
    .I(CLK_p),                 // Diff_p buffer input (connect directly to top-level port)
    .IB(CLK_n)                 // Diff_n buffer input (connect directly to top-level port)
);
// End of clk_ibufds instantiation
```

## VHDL Syntax

DIFF\_TERM can be set within the design by assigning the DIFF\_TERM generic on the instantiated differential buffer in the design.



**RECOMMENDED:** Use the instantiation template from the Language Templates or the *7 Series Libraries Guide for HDL Designs (UG768)* to specify the proper syntax.

## VHDL Syntax Example

The following example enables differential termination on the IBUFDS instance named `clk_ibufds`.

```
-- IBUFDS: Differential Input Buffer
--      Virtex-7
-- Xilinx HDL Language Template, version 2012.2
clk_ibufds : IBUFDS
generic map (
    DIFF_TERM => TRUE,          -- Differential Termination
    IBUF_LOW_PWR => TRUE,      -- Low power (TRUE) vs. performance (FALSE) setting for referenced
I/O standards
    IOSTANDARD => "DEFAULT")
port map (
    O => clk,                  -- Buffer output
    I => CLK_p,                -- Diff_p buffer input (connect directly to top-level port)
    IB => CLK_n                -- Diff_n buffer input (connect directly to top-level port)
);
-- End of clk_ibufds instantiation
```

## XDC Syntax

```
set_property DIFF_TERM TRUE [get_ports port_name]
```

### Where

- `port_name` is an input or bi-directional port connected to a differential buffer in the design

### XDC Syntax Example

```
# Enables differential termination on port named CLK_p
set_property DIFF_TERM TRUE [get_ports CLK_p]
```

### Alternative XDC Syntax Example

This property can be applied to the buffer instance:

```
set_property DIFF_TERM TRUE [get_cells instance_name]
```

Where

- `instance_name` is an input or bi-directional differential buffer instance in the design.

```
# Enables differential termination on buffer instance clk_ibufds
set_property DIFF_TERM TRUE [get_ports clk_ibufds]
```

**Note** When this property is set in both HDL code and in XDC, the XDC property takes precedence.

### Affected Steps in the Design

- I/O Planning
- Report Noise
- Report Power

### See Also

*7 Series Libraries Guide for HDL Designs (UG768)*

- IBUFDS
- IBUFDS\_INTERMDISABLE
- IBUFDS\_DIFF\_OUT
- IBUFDS\_DIFF\_OUT\_IBUFDISABLE
- IBUFDS\_DIFF\_OUT\_INTERMDISABLE
- IOBUFDS
- IOBUFDS\_DCIEN
- IOBUFDS\_DIFF\_OUT
- IOBUFDS\_DIFF\_OUT\_DCIEN
- IOBUFDS\_DIFF\_OUT\_INTERMDISABLE

---

## DONT\_TOUCH

DONT\_TOUCH directs the tool to not optimize a user hierarchy or instantiated component in the design so that optimization does not occur across its boundary. This can be used to assist floorplanning, analysis, and debug efforts, but it may inhibit optimization. This can result in a larger, slower design.



**RECOMMENDED:** Register all outputs of a module instance in which a DONT\_TOUCH is attached. To be most effective, apply this attribute before synthesis.

---

### Architecture Support

All architectures

### Applicable Elements

- Cells (get\_cells)  
User defined instance

### Values

- FALSE (default)  
Allow optimization across hierarchy.
- TRUE  
Preserve hierarchy by not allowing any optimization across hierarchy boundary.

### Syntax and Syntax Examples



**IMPORTANT:** Before copying syntax or coding examples from this PDF document for insertion into your code, see [Copying Syntax and Coding Examples from PDF Documents](#) in the Introduction to this guide.

---

### Verilog Syntax

Place the Verilog attribute immediately before the user hierarchy instantiation in the design:

```
(* DONT_TOUCH = "{TRUE|FALSE}" *)
```

### Verilog Syntax Example

```
// Preserve the hierarchy of instance CLK1_rst_sync
(* DONT_TOUCH = "TRUE" *) reset_sync #(
    .STAGES(5)
) CLK1_rst_sync (
    .RST_IN(RST | ~LOCKED),
    .CLK(clk1_100mhz),
    .RST_OUT(rst_clk1)
);
```

### VHDL Syntax

Declare the VHDL attribute as follows:

```
attribute DONT_TOUCH : string;
```

Specify the VHDL attribute as follows:

```
attribute DONT_TOUCH of name: label is "{TRUE|FALSE}";
```

*Where*

- name is either the instance name of a user defined instance in the design.

### VHDL Syntax Example

```
attribute DONT_TOUCH : string;
-- Preserve the hierarchy of instance CLK1_rst_sync
attribute DONT_TOUCH of CLK1_rst_sync: label is "TRUE";
...
CLK1_rst_sync : reset_sync
    PORT MAP (
        RST_IN => RST_LOCKED,
        CLK => clk1_100mhz,
        RST_OUT => rst_clk1
    );
```

### XDC Syntax

```
set_property DONT_TOUCH {TRUE|FALSE} [get_cells instance_name]
```

*Where*

- instance\_name is a register instances in the design.

### XDC Syntax Example

```
# Preserve the hierarchy of instance CLK1_rst_sync
set_property DONT_TOUCH TRUE [get_cells CLK1_rst_sync]
```

### Affected Steps in the Design

- synth\_design
- opt\_design
- phys\_opt\_design
- floorplanning

---

## DRIVE

DRIVE specifies output buffer drive strength in mA for output buffers configured with I/O standards that support programmable output drive strengths.

### Architecture Support

All architectures

### Applicable Elements

- Ports (get\_ports)
  - Output or bi-directional ports connected
- Cells (get\_cells)
  - Output Buffers (all OBUF variants)

### Values

Integer values:

- 2
- 4
- 6
- 8
- 12 (default)
- 16
- 24

### Syntax and Syntax Examples



**IMPORTANT:** Before copying syntax or coding examples from this PDF document for insertion into your code, see [Copying Syntax and Coding Examples from PDF Documents](#) in the Introduction to this guide.

---

### Verilog Syntax

When inferring I/O buffers, the DRIVE attribute can be set in the design using the proper Verilog attribute syntax placed before the top-level output port declaration:

```
(* DRIVE = "{2|4|6|8|12|16|24}" *)
```

### Verilog Syntax Example

```
// Sets the drive strength on the STATUS output port to 2 mA
(* DRIVE = "2" *) output STATUS,
```

### Alternative Verilog Syntax Example

If the output or bi-directional buffer is instantiated, DRIVE can be set within the design by assigning the DRIVE parameter on the instantiated output buffer in the design.



**RECOMMENDED:** Use the instantiation template from the Language Templates or the *7 Series Libraries Guide for HDL Designs (UG768)* to specify the proper syntax.

The following example sets the drive strength on the OBUF instance named `status_obuf` to 2 mA:

```
// OBUF: Single-ended Output Buffer
//      Virtex-7
// Xilinx HDL Language Template, version 2012.2

OBUF #(
  .DRIVE(2),      // Specify the output drive strength
  .IOSTANDARD("DEFAULT"), // Specify the output I/O standard
  .SLEW("SLOW") // Specify the output slew rate
) status_obuf (
  .O(STATUS),    // Buffer output (connect directly to top-level port)
  .I(status_int) // Buffer input
);

// End of status_obuf instantiation
```

### VHDL Syntax

When inferring I/O buffers, the DRIVE attribute can be set in the design using the proper VHDL attribute syntax placed before the top-level output port declaration.

Declare the VHDL attribute as follows:

```
attribute DRIVE : integer;
```

Specify the VHDL attribute as follows:

```
attribute DRIVE of port_name : signal is value;
```

Where

- `port_name` is a top-level output port in the design.

### VHDL Syntax Example

```
STATUS : out std_logic;
attribute DRIVE : integer;
-- Sets the drive strength on the STATUS output port to 2 mA
attribute DRIVE of STATUS : signal is 2;
```

### Alternative VHDL Syntax Example

If the output or bi-directional buffer is instantiated, DRIVE can be set within the design by assigning the DRIVE generic on the instantiated output buffer in the design.





**RECOMMENDED:** Use the instantiation template from the Language Templates or the *7 Series Libraries Guide for HDL Designs (UG768)* to specify the proper syntax.

The following example sets the drive strength on the OBUF instance named `status_obuf` to 2 mA.

```
-- OBUF: Single-ended Output Buffer
--      Virtex-7
-- Xilinx HDL Language Template, version 2012.2

status_obuf : OBUF
generic map (
  DRIVE => 2,
  IOSTANDARD => "DEFAULT",
  SLEW => "SLOW")
port map (
  O => STATUS,      -- Buffer output (connect directly to top-level port)
  I => status_int  -- Buffer input
);

-- End of status_obuf instantiation
```

## XDC Syntax

```
set_property DRIVE value [get_ports port_name]
```

### Where

- `port_name` is an output or bi-directional port in the design

### XDC Syntax Example

```
# Sets the drive strength of the port STATUS to 2 mA
set_property DRIVE 2 [get_ports STATUS]
```

**Note** When this property is set in both HDL code and in XDC, the XDC property takes precedence.

## Affected Steps in the Design

- I/O Planning
- Report Noise
- Report Power

## See Also

*7 Series Libraries Guide for HDL Designs (UG768)*

- OBUF
- OBUFT
- IOBUF
- IOBUF\_DCIEN
- IOBUF\_INTERM\_DISABLE

---

## HIODELAY\_GROUP

HIODELAY\_GROUP groups IDELAYCTRL components to their associated IDELAY or ODELAY instances for proper placement and replication.

### Difference Between HIODELAY\_GROUP and IODELAY\_GROUP

HIODELAY\_GROUP is uniquified per hierarchy.

Use HIODELAY\_GROUP when:

- You expect to have multiple instances of a module that contains an IDELAYCTRL.  
and
- That instance is not intended to be grouped with any IDELAY or ODELAY instances in other logical hierarchies.

### Architecture Support

All architectures

### Applicable Elements

- Cells (get\_cells)  
IDELAY, ODELAY, or IDELAYCTRL instances

### Values

Any specified group name

### Syntax and Syntax Examples



**IMPORTANT:** Before copying syntax or coding examples from this PDF document for insertion into your code, see [Copying Syntax and Coding Examples from PDF Documents](#) in the Introduction to this guide.

---

### Verilog Syntax

Place the Verilog attribute immediately before the instantiation of an IDELAY, ODELAY, or IDELAYCTRL in the design.

```
(* HIODELAY_GROUP = "value" *)
```

## Verilog Syntax Example

```
// Specifies a group name of DDR_INTERFACE to an instantiated IDELAYCTRL
// IDELAYCTRL: IDELAYE2/ODELAYE2 Tap Delay Value Control
//           Virtex-7
// Xilinx HDL Language Template, version 2012.2
(* HIODELAY_GROUP = "DDR_INTERFACE" *) // Specifies group name for associated IDELAYS/ODELAYS
and IDELAYCTRL
IDELAYCTRL DDR_IDELAYCTRL_inst (
    .RDY(),           // 1-bit output: Ready output
    .REFCLK(REFCLK), // 1-bit input: Reference clock input
    .RST(1'b0)       // 1-bit input: Active high reset input
);
// End of DDR_IDELAYCTRL_inst instantiation
```

## VHDL Syntax

Declare the VHDL attribute as follows:

```
attribute HIODELAY_GROUP : string;
```

For an instantiated instance, specify the VHDL attribute as follows:

```
attribute HIODELAY_GROUP of instance_name : label is "group_name";
```

*Where*

- `instance_name` is the instance name of an instantiated IDELAY, ODELAY, or IDELAYCTRL.

## VHDL Syntax Example

```
// Specifies a group name of DDR_INTERFACE to an instantiated IDELAYCTRL
attribute HIODELAY_GROUP : STRING;
attribute HIODELAY_GROUP of DDR_IDELAYCTRL_inst: label is "DDR_INTERFACE";
begin
    -- IDELAYCTRL: IDELAYE2/ODELAYE2 Tap Delay Value Control
    --           Virtex-7
    -- Xilinx HDL Language Template, version 2012.2
    DDR_IDELAYCTRL_inst : IDELAYCTRL
    port map (
        RDY => open,           -- 1-bit output: Ready output
        REFCLK => REFCLK,     -- 1-bit input: Reference clock input
        RST => '0'             -- 1-bit input: Active high reset input
    );
    -- End of DDR_IDELAYCTRL_inst instantiation
```

## XDC Syntax

```
set_property HIODELAY_GROUP group_name [get_cells instance_name]
```

*Where*

- `instance_name` is an the instance name of an IDELAY, ODELAY, or IDELAYCTRL.

## XDC Syntax Example

```
# Specifies a group name of DDR_INTERFACE to an instantiated IDELAYCTRL
set_property HIODELAY_GROUP DDR_INTERFACE [get_cells DDR_IDELAYCTRL_inst]
```

**Note** When this property is set in both HDL code and in XDC, the XDC property takes precedence.

## Affected Steps in the Design

place\_design

## See Also

IODELAY\_GROUP

*7 Series Libraries Guide for HDL Designs (UG768)*

- IDELAYCTRL
- IDELAYE2
- ODELAYE2

---

## HLUTNM

HLUTNM instructs the tool to place two LUT5, SRL16, or LUTRAM components with compatible inputs into the same LUT6 site. Specify the HLUTNM in pairs per hierarchy, with two of these specified on compatible instance types with the same group name.

### Difference Between HLUTNM and LUTNM

HLUTNM is uniquified per hierarchy.

- Use HLUTNM when you expect to have multiple instances of a module that contains LUTs to be grouped together.
- Use LUTNM to group two LUTs that exist in different hierarchies.

### Architecture Support

All architectures

### Applicable Elements

Cells (get\_cells)

- LUT (LUT1, LUT2, LUT3, LUT4, LUT5)
- SRL (SRL16E)
- LUTRAM (RAM32X1D, RAM32X1S)

### Values

A unique group name

### Syntax and Syntax Examples



**IMPORTANT:** Before copying syntax or coding examples from this PDF document for insertion into your code, see [Copying Syntax and Coding Examples from PDF Documents](#) in the Introduction to this guide.

---

### Verilog Syntax

Place the Verilog attribute immediately before the instantiation of a LUT in the design.

The Verilog attribute must be used in pairs in the same logical hierarchy in the design.

```
(* HLUTNM = "group_name" *)
```

## Verilog Syntax Example

```
// Designates state0_inst to be placed in same LUT6 as state1_inst
// LUT5: 5-input Look-Up Table with general output (Mapped to a LUT6)
//      Virtex-7
// Xilinx HDL Language Template, version 2012.2
(* HLLUTNM = "LUT_group1" *) LUT5 #(
  .INIT(32'h02a2aea2) // Specify LUT Contents
) state0_inst (
  .O(state_out[0]), // LUT general output
  .I0(state_in[0]), // LUT input
  .I1(state_in[1]), // LUT input
  .I2(state_in[2]), // LUT input
  .I3(state_in[3]), // LUT input
  .I4(state_in[4]) // LUT input
);
// End of state0_inst instantiation
// LUT5: 5-input Look-Up Table with general output (Mapped to a LUT6)
//      Virtex-7
// Xilinx HDL Language Template, version 2012.2
(* HLLUTNM = "LUT_group1" *) LUT5 #(
  .INIT(32'h00330073) // Specify LUT Contents
) state1_inst (
  .O(state_out[1]), // LUT general output
  .I0(state_in[0]), // LUT input
  .I1(state_in[1]), // LUT input
  .I2(state_in[2]), // LUT input
  .I3(state_in[3]), // LUT input
  .I4(state_in[4]) // LUT input
);
// End of state1_inst instantiation
```

## VHDL Syntax

Declare the VHDL attribute as follows:

```
attribute HLLUTNM : string;
```

For an instantiated instance, specify the VHDL attribute as follows:

```
attribute HLLUTNM of instance_name : label is "group_name";
```

*Where*

- instance\_name is a LUT1, LUT2, LUT3, LUT4, LUT5, SRL16, or LUTRAM instance in the code.

The VHDL attribute must be used in pairs in the same logical hierarchy in the design.

## VHDL Syntax Example

```
-- Designates state0_inst to be placed in same LUT6 as state1_inst
attribute HLUTNM : string;
attribute HLUTNM of state0_inst : label is "LUT_group1";
attribute HLUTNM of state1_inst : label is "LUT_group1";
begin
  -- LUT5: 5-input Look-Up Table with general output (Mapped to SliceM LUT6)
  --      Virtex-7
  -- Xilinx HDL Language Template, version 2012.2
  state0_inst : LUT5
  generic map (
    INIT => X"a2a2aea2") -- Specify LUT Contents
  port map (
    O => state_out(0), -- LUT general output
    I0 => state_in(0), -- LUT input
    I1 => state_in(1), -- LUT input
    I2 => state_in(2), -- LUT input
    I3 => state_in(3), -- LUT input
    I4 => state_in(4)  -- LUT input
  );
  -- End of state0_inst instantiation
  -- LUT5: 5-input Look-Up Table with general output (Mapped to SliceM LUT6)
  --      Virtex-7
  -- Xilinx HDL Language Template, version 2012.2
  state1_inst : LUT5
  generic map (
    INIT => X"00330073") -- Specify LUT Contents
  port map (
    O => state_out(1), -- LUT general output
    I0 => state_in(0), -- LUT input
    I1 => state_in(1), -- LUT input
    I2 => state_in(2), -- LUT input
    I3 => state_in(3), -- LUT input
    I4 => state_in(4)  -- LUT input
  );
  -- End of state1_inst instantiation
```

## XDC Syntax

```
set_property HLUTNM group_name [get_cells instance_name]
```

### Where

- `instance_name` is a LUT1, LUT2, LUT3, LUT4, LUT5, SRL16, or LUTRAM instance in the design.

### XDC Syntax Example

```
# Designates state0_inst LUT5 to be placed in same LUT6 as state1_inst
set_property HLUTNM LUT_group1 [get_cells state0_inst]
set_property HLUTNM LUT_group1 [get_cells state1_inst]
```

**Note** When this property is set in both HDL code and in XDC, the XDC property takes precedence.

## Affected Steps in the Design

```
place_design
```



## See Also

LUTNM

## IN\_TERM

IN\_TERM specifies an uncalibrated input termination impedance value.

IN\_TERM is supported on High Range (HR) bank inputs only.

**Note** For inputs in High Performance (HP) banks, use Digital Controlled Impedance (DCI) circuits for on-chip termination.

### Architecture Support

All architectures on High Range (HR) bank inputs only

### Applicable Elements

- Ports (get\_ports)
  - Input or bi-directional ports connected
- Cells (get\_cells)
  - Input Buffers (all IBUF variants)

### Values

- NONE (default)
- UNTUNED\_SPLIT\_25
- UNTUNED\_SPLIT\_50
- UNTUNED\_SPLIT\_75

### Syntax and Syntax Examples



**IMPORTANT:** Before copying syntax or coding examples from this PDF document for insertion into your code, see [Copying Syntax and Coding Examples from PDF Documents](#) in the Introduction to this guide.

#### Verilog Syntax

The IN\_TERM attribute can be set in the design using the proper Verilog attribute syntax placed before the top-level output port declaration:

```
(* IN_TERM = "{NONE|UNTUNED_SPLIT_25|UNTUNED_SPLIT_50|UNTUNED_SPLIT_75}" *)
```

#### Verilog Syntax Example

```
// Sets an on-chip input impedance of 50 Ohms to input ACT5
(* IN_TERM = "UNTUNED_SPLIT_50" *) input ACT5,
```

## VHDL Syntax

The IN\_TERM attribute can be set in the design using the proper VHDL attribute syntax placed before the top-level output port declaration.

Declare the VHDL attribute as follows:

```
attribute IN_TERM : string;
```

Specify the VHDL attribute as follows:

```
attribute IN_TERM of port_name : signal is value;
```

*Where*

- `port_name` is a top-level output port in the design.

### VHDL Syntax Example

```
ACT5 : in std_logic;  
attribute IN_TERM : string;  
-- Sets an on-chip input impedance of 50 Ohms to input ACT5  
attribute IN_TERM of ACT5 : signal is "UNTUNED_SPLIT_50";
```

## XDC Syntax

```
set_property IN_TERM value [get_ports port_name]
```

*Where*

- `port_name` is an output or bi-directional port in the design.

### XDC Syntax Example

```
# Sets an on-chip input impedance of 50 Ohms to input ACT5  
set_property IN_TERM UNTUNED_SPLIT_50 [get_ports ACT5]
```

**Note** When this property is set in both HDL code and in XDC, the XDC property takes precedence.

## Affected Steps in the Design

- I/O Planning
- Report Noise
- Report Power

## See Also

DCI\_VALUE

---

## INTERNAL\_VREF

INTERNAL\_VREF specifies the use of an internal regulator on a bank to supply the voltage reference for standards requiring a reference voltage.

### Architecture Support

All architectures

### Applicable Elements

I/O Bank (get\_iobanks)

### Values

- 0.60
- 0.675
- 0.75
- 0.90

### Syntax and Syntax Examples



**IMPORTANT:** Before copying syntax or coding examples from this PDF document for insertion into your code, see [Copying Syntax and Coding Examples from PDF Documents](#) in the Introduction to this guide.

---

#### Verilog Syntax

Not applicable

#### VHDL Syntax

Not applicable

#### XDC Syntax

```
set_property INTERNAL_VREF {value} [get_iobanks bank]
```

*Where*

- `value` is the reference voltage value.

## XDC Syntax Example

```
# Designate Bank 14 to have a reference voltage of 0.75 Volts  
set_property INTERNAL_VREF 0.75 [get_iobanks 14]
```

## Affected Steps in the Design

- I/O planning
- place\_design
- drc
- report\_power

## IOB

IOB directs the tool to place a register in the input or output logic to improve I/O timing.

### Architecture Support

All architectures

### Applicable Elements


- Ports (get\_ports)
  - Any port connected to a register
- Cells (get\_cells)
  - Registers connected directly to a top-level port

### Values

- TRUE
- FALSE (default)

### Syntax and Syntax Examples

---

 **IMPORTANT:** Before copying syntax or coding examples from this PDF document for insertion into your code, see [Copying Syntax and Coding Examples from PDF Documents](#) in the Introduction to this guide.

---

#### Verilog Syntax

The IOB attribute can be set in the design using the proper Verilog attribute syntax placed before the top-level output port declaration:

```
(* IOB = "{TRUE|FALSE}" *)
```

#### Verilog Syntax Example

```
// Place the register connected to ACK in the input logic site
(* IOB = "TRUE" *) input ACK,
```

#### Alternative Verilog Syntax Example

The IOB attribute can be placed on an instantiated or inferred register connected to a top-level port.

Place the register connected to ACK in the input logic site.

```
input ACK;
(* IOB = "TRUE" *) reg ack_reg = 1'b0;
always @(posedge CLK)
    ack_reg = 1'b0;
```

## VHDL Syntax

The IOB attribute can be set in the design using the proper VHDL attribute syntax placed before the top-level output port declaration.

Declare the VHDL attribute as follows:

```
attribute IOB : string;
```

Specify the VHDL attribute as follows:

```
attribute IOB of <port_name>: signal is "{TRUE|FALSE}";
```

*Where*

- `port_name` is a top-level output port in the design.

## VHDL Syntax Example

```
ACK : in std_logic;
attribute IOB : string;
-- Place the register connected to ACK in the input logic site
attribute IOB of ACK: signal is "TRUE";
```

## Alternative VHDL Syntax Example

The IOB attribute can be placed on an instantiated or inferred register connected to a top-level port.

Place the register connected to ACK in the input logic site.

## XDC Syntax

```
set_property IOB value [get_ports port_name]
```

*Where*

- `value` is TRUE or FALSE.

## XDC Syntax Example

```
# Place the register connected to ACK in the input logic site
set_property IOB TRUE [get_ports ACK]
```

**Note** When this property is set in both HDL code and in XDC, the XDC property takes precedence.

## Affected Steps in the Design

place\_design

---

## IODELAY\_GROUP

IODELAY\_GROUP Groups IDELAYCTRL components to their associated IDELAY and ODELAY instances so that proper placement and replication may occur in the design.

### Difference Between IODELAY\_GROUP and HIODELAY\_GROUP

IODELAY\_GROUP can group elements in different hierarchies.

Use IODELAY\_GROUP to group I/O delay components in different hierarchies together.

### Architecture Support

All architectures

### Applicable Elements

- Cells (get\_cells)
- IDELAY, ODELAY, or IDELAYCTRL instances

### Values

Any specified group name

### Syntax and Syntax Examples



**IMPORTANT:** Before copying syntax or coding examples from this PDF document for insertion into your code, see [Copying Syntax and Coding Examples from PDF Documents](#) in the Introduction to this guide.

---

### Verilog Syntax

Place the Verilog attribute immediately before the instantiation of an IDELAY, ODELAY, or IDELAYCTRL in the design.

```
(* IODELAY_GROUP = "value" *)
```



## Verilog Syntax Example

```
// Specifies a group name of DDR_INTERFACE to an instantiated IDELAYCTRL
// IDELAYCTRL: IDELAYE2/ODELAYE2 Tap Delay Value Control
//           Virtex-7
// Xilinx HDL Language Template, version 2012.2
(* IODELAY_GROUP = "DDR_INTERFACE" *) // Specifies group name for associated IDELAYs/ODELAYs
and IDELAYCTRL
  IDELAYCTRL DDR_IDELAYCTRL_inst (
    .RDY(),           // 1-bit output: Ready output
    .REFCLK(REFCLK), // 1-bit input: Reference clock input
    .RST(1'b0)       // 1-bit input: Active high reset input
  );
// End of DDR_IDELAYCTRL_inst instantiation
```

## VHDL Syntax

Declare the VHDL attribute as follows:

```
attribute IODELAY_GROUP : string;
```

For an instantiated instance, specify the VHDL attribute as follows:

```
attribute IODELAY_GROUP of instance_name : label is "group_name";
```

*Where*

- `instance_name` is the instance name of an instantiated IDELAY, ODELAY, or IDELAYCTRL.

## VHDL Syntax Example

```
// Specifies a group name of DDR_INTERFACE to an instantiated IDELAYCTRL
attribute IODELAY_GROUP : STRING;
attribute IODELAY_GROUP of DDR_IDELAYCTRL_inst: label is "DDR_INTERFACE";
begin
  -- IDELAYCTRL: IDELAYE2/ODELAYE2 Tap Delay Value Control
  --           Virtex-7
  -- Xilinx HDL Language Template, version 2012.2
  DDR_IDELAYCTRL_inst : IDELAYCTRL
  port map (
    RDY => open,           -- 1-bit output: Ready output
    REFCLK => REFCLK,     -- 1-bit input: Reference clock input
    RST => '0'             -- 1-bit input: Active high reset input
  );
  -- End of DDR_IDELAYCTRL_inst instantiation
```

## XDC Syntax

```
set_property IODELAY_GROUP group_name [get_cells instance_name]
```

*Where*

- `instance_name` is an the instance name of an IDELAY, ODELAY, or IDELAYCTRL.

## XDC Syntax Example

```
# Specifies a group name of DDR_INTERFACE to an instantiated IDELAYCTRL
set_property IODELAY_GROUP DDR_INTERFACE [get_cells DDR_IDELAYCTRL_inst]
```

**Note** When this property is set in both HDL code and in XDC, the XDC property takes precedence.

## Affected Steps in the Design

place\_design

## See Also

HIODELAY\_GROUP

*7 Series Libraries Guide for HDL Designs (UG768)*

- IDELAYCTRL
- IDELAYE2
- ODELAYE2

---

## IOSTANDARD

IOSTANDARD specifies which programmable I/O Standard to use to configure input, output, or bi-directional ports in the design. You must specify an IOSTANDARD on all ports in the design in order to create a bitstream.

### Architecture Support

All architectures

### Applicable Elements

- Ports (get\_ports)
  - Any port in the design
- Cells (get\_cells)
  - I/O Buffers (all IBUF, OBUF, and IOBUF variants)

### Values

A valid I/O Standard

See *SelectIO Resources User Guide* for legal values.

### Syntax and Syntax Examples



**IMPORTANT:** Before copying syntax or coding examples from this PDF document for insertion into your code, see [Copying Syntax and Coding Examples from PDF Documents](#) in the Introduction to this guide.

---

### Verilog Syntax

When inferring I/O buffers, the DRIVE attribute can be set in the design using the proper Verilog attribute syntax placed before the top-level output port declaration.

```
(* IOSTANDARD = "value" *)
```

#### Verilog Syntax Example

```
// Sets the I/O Standard on the STATUS output to LVCMOS12
(* IOSATNDARD = "LVCMOS12" *) output STATUS,
```

#### Alternative Verilog Syntax Example

If the I/O buffer is instantiated, IOSATNDARD can be set within the design by assigning the IOSTANDARD parameter on the instantiated I/O buffer in the design.



**RECOMMENDED:** Use the instantiation template from the Language Templates or the *7 Series Libraries Guide for HDL Designs (UG768)* to specify the proper syntax.

The following example sets the I/O Standard on the STATUS output to LVCMOS12.

```
// OBUF: Single-ended Output Buffer
//      Virtex-7
// Xilinx HDL Language Template, version 2012.2

OBUF #(
  .DRIVE(12),      // Specify the output drive strength
  .IOSTANDARD("LVCMOS12"), // Specify the output I/O standard
  .SLEW("SLOW") // Specify the output slew rate
) status_obuf (
  .O(STATUS),      // Buffer output (connect directly to top-level port)
  .I(status_int) // Buffer input
);

// End of status_obuf instantiation
```

## VHDL Syntax

When inferring I/O buffers, the IOSTANDARD attribute can be set in the design using the proper VHDL attribute syntax placed before the top-level output port declaration.

Declare the VHDL attribute as follows:

```
attribute IOSTANDARD : string;
```

Specify the VHDL attribute as follows:

```
attribute IOSTANDARD of <port_name>: signal is "<standard>";
```

*Where*

- port\_name is a top-level output port in the design.

## VHDL Syntax Example

```
STATUS : out std_logic;
attribute IOSTANDARD : string;
-- Sets the I/O Standard on the STATUS output to LVCMOS12
attribute IOSTANDARD of STATUS: signal is "LVCMOS12";
```

## Alternative VHDL Syntax Example

If the I/O buffer is instantiated, IOSTANDARD can be set within the design by assigning the IOSTANDARD generic on the instantiated I/O buffer in the design.



**RECOMMENDED:** Use the instantiation template from the Language Templates or the *7 Series Libraries Guide for HDL Designs (UG768)* to specify the proper syntax.

The following example sets the I/O Standard on the STATUS output to LVCMOS12

```
-- OBUF: Single-ended Output Buffer
--      Virtex-7
-- Xilinx HDL Language Template, version 2012.2

status_obuf : OBUF
generic map (
  DRIVE => 12,
  IOSTANDARD => "LVCMOS12",
  SLEW => "SLOW")
port map (
  O => STATUS,      -- Buffer output (connect directly to top-level port)
  I => status_int   -- Buffer input
);

-- End of status_obuf instantiation
```

## XDC Syntax

```
set_property IOSTANDARD value [get_ports port_name]
```

*Where*

- `port_name` is an top-level port in the design.

## XDC Syntax Example

```
# Sets the I/O Standard on the STATUS output to LVCMOS12
set_property IOSTANDARD LVCMOS12 [get_ports STATUS]
```

**Note** When this property is set in both HDL code and in XDC, the XDC property takes precedence.

## Affected Steps in the Design

- I/O Planning
- Report Noise
- Report Power
- Report DRC
- `place_design`

## See Also

*7 Series Libraries Guide for HDL Designs (UG768)*

- OBUF
- OBUFT
- IOBUF

## Chapter 2: Vivado Design Suite Properties

- IOBUF\_DCIEN
- IOBUF\_INTERM\_DISABLE

For legal values, see the *SelectIO Resources User Guide*.

---

## KEEP\_HIERARCHY

KEEP\_HIERARCHY directs the tool to retain a user hierarchy in the design so that optimization does not occur across its boundary. This can be used to assist floorplanning, analysis, and debug efforts, but may inhibit optimization. This can result in a larger, slower design.



**RECOMMENDED:** To avoid these negative effects, register all outputs of a module instance in which a KEEP\_HIERARCHY is attached. To be most effective, apply this attribute before synthesis.

---

### Architecture Support

All architectures

### Applicable Elements

- Cells (get\_cells)
- User defined instance

### Values

- FALSE (default)  
Allow optimization across hierarchy.
- TRUE  
Preserve hierarchy by not allowing any optimization across hierarchy boundary.

### Syntax and Syntax Examples



**IMPORTANT:** Before copying syntax or coding examples from this PDF document for insertion into your code, see [Copying Syntax and Coding Examples from PDF Documents](#) in the Introduction to this guide.

---

### Verilog Syntax

Place the Verilog attribute immediately before the user hierarchy instantiation in the design:

```
(* KEEP_HIERARCHY = "{TRUE|FALSE}" *)
```

### Verilog Syntax Example

```
// Preserve the hierarchy of instance CLK1_rst_sync
(* KEEP_HIERARCHY = "TRUE" *) reset_sync #(
    .STAGES(5)
) CLK1_rst_sync (
    .RST_IN(RST | ~LOCKED),
    .CLK(clk1_100mhz),
    .RST_OUT(rst_clk1)
);
```

### VHDL Syntax

Declare the VHDL attribute as follows:

```
attribute KEEP_HIERARCHY : string;
```

Specify the VHDL attribute as follows:

```
attribute KEEP_HIERARCHY of name: label is "{TRUE|FALSE}";
```

*Where*

- name is either the instance name of a user defined instance in the design.

### VHDL Syntax Example

```
attribute KEEP_HIERARCHY : string;
-- Preserve the hierarchy of instance CLK1_rst_sync
attribute KEEP_HIERARCHY of CLK1_rst_sync: label is "TRUE";
...
CLK1_rst_sync : reset_sync
    PORT MAP (
        RST_IN => RST_LOCKED,
        CLK => clk1_100mhz,
        RST_OUT => rst_clk1
    );
```

### XDC Syntax

```
set_property KEEP_HIERARCHY {TRUE|FALSE} [get_cells instance_name]
```

*Where*

- instance\_name is a register instances in the design.

### XDC Syntax Example

```
# Preserve the hierarchy of instance CLK1_rst_sync
set_property KEEP_HIERARCHY TRUE [get_cells CLK1_rst_sync]
```

## Affected Steps in the Design

- synth\_design
- opt\_design
- phys\_opt\_design
- floorplanning



---

## LOC

LOC specifies a specific placement of a primitive component within the device.

### Architecture Support

All architectures

### Applicable Elements

Cells (get\_cells)

- Any primitive

### Values

Site name (for example, SLICE\_X15Y14 or RAMB18\_X6Y9)

### Syntax and Syntax Examples



**IMPORTANT:** Before copying syntax or coding examples from this PDF document for insertion into your code, see [Copying Syntax and Coding Examples from PDF Documents](#) in the Introduction to this guide.

---

### Verilog Syntax

Place the Verilog attribute immediately before the instantiation of a component in the design.

#### Alternative Verilog Syntax Example

The Verilog attribute can be placed before the reg declaration of an inferred register, SRL, or LUTRAM in the design when that reg can be placed into a single device site:

```
(* LOC = "site_name" *)
```

```
// Designates placed_reg to be placed in Slice site SLICE_X0Y0
(* LOC = "SLICE_X0Y0" *) reg placed_reg;
```

### VHDL Syntax

Declare the VHDL attribute as follows:

```
attribute LOC : string;
```

For an instantiated instance, specify the VHDL attribute as follows:

```
attribute LOC of instance_name : label is "site_name";
```

### Where

- `instance_name` is the instance name of an instantiated primitive.

### VHDL Syntax Example

```
-- Designates instantiated register instance placed_reg to be placed
-- in Slice site SLICE_X0Y0
attribute LOC of placed_reg : label is "SLICE_X0Y0";
```

For an inferred instance, Specify the VHDL attribute as follows:

```
attribute LOC of signal_name : signal is "site_name";
```

### Where

- `signal_name` is the signal name of an inferred primitive which can be placed into a single site.

### VHDL Syntax Example

```
-- Designates inferred register placed_reg to be placed in Slice site SLICE_X0Y0
attribute LOC of placed_reg : signal is "SLICE_X0Y0";
```

### XDC Syntax

```
set_property LOC site_name [get_cells instance_name]
```

### Where

- `instance_name` is a primitive instance in the design.

### XDC Syntax Example

```
# Designates placed_reg to be placed in Slice site SLICE_X0Y0
set_property LOC SLICE_X0Y0 [get_cells placed_reg]
```

**Note** When this property is set in both HDL code and in XDC, the XDC property takes precedence.

### Affected Steps in the Design

- Design Floorplanning
- `place_design`

### See Also

- BEL
- PACKAGE\_PIN

---

## LUTNM

LUTNM instructs the tool to place two LUT5, SRL16, or LUTRAM components with compatible inputs into the same LUT6 site. The LUTNM must be specified in pairs, with two of these specified on compatible instance types with the same group name.

### Difference Between LUTNM and HLUTNM

LUTNM can be used to combine two LUTs that exist in different user hierarchy.

Use LUTNM to group two LUTs that exist in the same user hierarchy.

### Architecture Support

All architectures

### Applicable Elements

Cells (get\_cells)

- LUTs (LUT1, LUT2, LUT3, LUT4, LUT5)
- SRLs (SRL16E)
- LUTRAMs (RAM32X1D, RAM32X1S)

### Values

A unique group name

### Syntax and Syntax Examples



**IMPORTANT:** Before copying syntax or coding examples from this PDF document for insertion into your code, see [Copying Syntax and Coding Examples from PDF Documents](#) in the Introduction to this guide.

---

### Verilog Syntax

Place the Verilog attribute immediately before the instantiation of a LUT in the design.

The Verilog attribute must be used in pairs in the same logical hierarchy in the design.

```
(* LUTNM = "group_name" *)
```

### Verilog Syntax Example

```
// Designates state0_inst to be placed in same LUT6 as state1_inst
// LUT5: 5-input Look-Up Table with general output (Mapped to a LUT6)
//      Virtex-7
// Xilinx HDL Language Template, version 2012.2
(* LUTNM = "LUT_group1" *) LUT5 #(
  .INIT(32'h02a2aea2) // Specify LUT Contents
) state0_inst (
  .O(state_out[0]), // LUT general output
  .I0(state_in[0]), // LUT input
  .I1(state_in[1]), // LUT input
  .I2(state_in[2]), // LUT input
  .I3(state_in[3]), // LUT input
  .I4(state_in[4]) // LUT input
);
// End of state0_inst instantiation
// LUT5: 5-input Look-Up Table with general output (Mapped to a LUT6)
//      Virtex-7
// Xilinx HDL Language Template, version 2012.2
(* LUTNM = "LUT_group1" *) LUT5 #(
  .INIT(32'h00330073) // Specify LUT Contents
) state1_inst (
  .O(state_out[1]), // LUT general output
  .I0(state_in[0]), // LUT input
  .I1(state_in[1]), // LUT input
  .I2(state_in[2]), // LUT input
  .I3(state_in[3]), // LUT input
  .I4(state_in[4]) // LUT input
);
// End of state1_inst instantiation
```

### VHDL Syntax

Declare the VHDL attribute as follows:

```
attribute LUTNM : string;
```

For an instantiated instance, specify the VHDL attribute as follows:

```
attribute LUTNM of instance_name : label is "group_name";
```

*Where*

- `instance_name` is a LUT1, LUT2, LUT3, LUT4, LUT5, SRL16, or LUTRAM instance in the code.

The VHDL attribute must be used in pairs in the same logical hierarchy in the design.

## VHDL Syntax Example

```
-- Designates state0_inst to be placed in same LUT6 as state1_inst
attribute LUTNM : string;
attribute LUTNM of state0_inst : label is "LUT_group1";
attribute LUTNM of state1_inst : label is "LUT_group1";
begin
    -- LUT5: 5-input Look-Up Table with general output (Mapped to SliceM LUT6)
    --      Virtex-7
    -- Xilinx HDL Language Template, version 2012.2
    state0_inst : LUT5
    generic map (
        INIT => X"a2a2aea2") -- Specify LUT Contents
    port map (
        O => state_out(0), -- LUT general output
        I0 => state_in(0), -- LUT input
        I1 => state_in(1), -- LUT input
        I2 => state_in(2), -- LUT input
        I3 => state_in(3), -- LUT input
        I4 => state_in(4)  -- LUT input
    );
    -- End of state0_inst instantiation
    -- LUT5: 5-input Look-Up Table with general output (Mapped to SliceM LUT6)
    --      Virtex-7
    -- Xilinx HDL Language Template, version 2012.2
    state1_inst : LUT5
    generic map (
        INIT => X"00330073") -- Specify LUT Contents
    port map (
        O => state_out(1), -- LUT general output
        I0 => state_in(0), -- LUT input
        I1 => state_in(1), -- LUT input
        I2 => state_in(2), -- LUT input
        I3 => state_in(3), -- LUT input
        I4 => state_in(4)  -- LUT input
    );
    -- End of state1_inst instantiation
```

## XDC Syntax

```
set_property LUTNM group_name [get_cells instance_name]
```

### Where

- `instance_name` is a LUT1, LUT2, LUT3, LUT4, LUT5, SRL16, or LUTRAM instance in the design.

### XDC Syntax Example

```
# Designates state0_inst LUT5 to be placed in same LUT6 as state1_inst
set_property LUTNM LUT_group1 [get_cells U1/state0_inst]
set_property LUTNM LUT_group1 [get_cells U2/state1_inst]
```

**Note** When this property is set in both HDL code and in XDC, the XDC property takes precedence.

## Affected Steps in the Design

```
place_design
```

## See Also

HLUTNM

---

## MARK\_DEBUG

Use MARK\_DEBUG to specify that a net in the design should be debugged using the ChipScope™ tool. This may prevent optimization that may have otherwise occurred to that signal. However, it will provide an easy means to later observe the values on this signal during FPGA operation.

### Architecture Support

All architectures

### Applicable Elements

Nets (get\_nets)

- Any net in the design accessible to the internal array.

**Note** Some nets may have dedicated connectivity or other aspects that prohibit visibility.

### Values

- TRUE
- FALSE

### Syntax and Syntax Examples



**IMPORTANT:** Before copying syntax or coding examples from this PDF document for insertion into your code, see [Copying Syntax and Coding Examples from PDF Documents](#) in the Introduction to this guide.

---

### Verilog Syntax

The MARK\_DEBUG attribute can be set in the design using the proper Verilog attribute syntax placed before the top-level output port declaration:

```
(* MARK_DEBUG = "{TRUE|FALSE}" *)
```

#### Verilog Syntax Example

```
// Marks an internal wire for ChipScope debug  
(* MARK_DEBUG = "TRUE" *) wire debug_wire,
```

## VHDL Syntax

The MARK\_DEBUG attribute can be set in the design using the proper VHDL attribute syntax placed before the top-level output port declaration.

Declare the VHDL attribute as follows:

```
attribute MARK_DEBUG : string;
```

Specify the VHDL attribute as follows:

```
attribute MARK_DEBUG of signal_name : signal is "{TRUE|FALSE}";
```

*Where*

- `signal_name` is an internal signal in the design.

### VHDL Syntax Example

```
signal debug_wire : std_logic;  
attribute MARK_DEBUG : string;  
-- Marks an internal wire for ChipScope debug  
attribute MARK_DEBUG of debug_wire : signal is "TRUE";
```

## XDC Syntax

```
set_property MARK_DEBUG value [get_nets net_name]
```

*Where*

- `net_name` is a signal name in the design.

### XDC Syntax Example

```
# Marks an internal wire for ChipScope debug  
set_property MARK_DEBUG TRUE [get_nets debug_wire]
```

## Affected Steps in the Design

- `place_design`
- `ChipScope`

## See Also

DONT\_TOUCH



---

## PACKAGE\_PIN

PACKAGE\_PIN specifies a specific placement of a top-level port in the logical design to a physical package pin on the device.

### Architecture Support

All architectures

### Applicable Elements

Ports (get\_ports)

- Any top-level port

### Values

Package pin name

### Syntax and Syntax Examples



**IMPORTANT:** Before copying syntax or coding examples from this PDF document for insertion into your code, see [Copying Syntax and Coding Examples from PDF Documents](#) in the Introduction to this guide.

---

#### Verilog Syntax

Place the Verilog attribute immediately before the port declaration in the design:

```
(* PACKAGE_PIN = "pin_name" *)
```

##### Verilog Syntax Example

```
// Designates port CLK to be placed on pin B26
(* PACKAGE_PIN = "B26" *) input CLK;
```

#### VHDL Syntax

Declare the VHDL attribute as follows:

```
attribute PACKAGE_PIN : string;
```

Specify the VHDL attribute as follows:

```
attribute PACKAGE_PIN of port_name : signal is "pin_name";
```

##### VHDL Syntax Example

```
-- Designates CLK to be placed on pin B26
attribute PACKAGE_PIN of CLK : signal is "B26";
```

## XDC Syntax

```
set_property PACKAGE_PIN pin_name [get_ports port_name]
```

## XDC Syntax Example

```
# Designates CLK to be placed on pin B26  
set_property PACKAGE_PIN B26 [get_ports CLK]
```

**Note** When this property is set in both HDL code and in XDC, the XDC property takes precedence.

## Affected Steps in the Design

- Pin planning
- place\_design

## See Also

LOC

---

## PROHIBIT

PROHIBIT specifies that a particular pin or site in the chip cannot be used for placement of the design.

### Architecture Support

All architectures

### Applicable Elements

- Sites (get\_sites)
- BELs (get\_bels)

### Values

1

### Syntax and Syntax Examples



**IMPORTANT:** Before copying syntax or coding examples from this PDF document for insertion into your code, see [Copying Syntax and Coding Examples from PDF Documents](#) in the Introduction to this guide.

---

#### Verilog Syntax

Not applicable

#### VHDL Syntax

Not applicable

#### XDC Syntax

```
set_property PROHIBIT 1 [get_sites site]
```

#### XDC Syntax Example

```
# Prohibit the use of package pin Y32  
set_property prohibit 1 [get_sites Y32]
```

### Affected Steps in the Design

- I/O planning
- place\_design

## SLEW

SLEW specifies output buffer slew rate for output buffers configured with I/O standards that support programmable output slew rates.

### Architecture Support

All architectures

### Applicable Elements

- Ports (get\_ports)
  - Output or bi-directional ports connected
- Cells (get\_cells)
  - Output Buffers (all OBUF variants)

### Values

- SLOW (default)
- FAST

### Syntax and Syntax Examples



**IMPORTANT:** Before copying syntax or coding examples from this PDF document for insertion into your code, see [Copying Syntax and Coding Examples from PDF Documents](#) in the Introduction to this guide.

#### Verilog Syntax

When inferring I/O buffers, the SLEW attribute can be set in the design using the proper Verilog attribute syntax placed before the top-level output port declaration:

```
(* DRIVE = "{SLOW|FAST}" *)
```

#### Verilog Syntax Example

```
// Sets the Slew rate to be FAST
(* SLEW = "FAST" *) output FAST_DATA,
```

#### Alternative Verilog Syntax Example

If the output or bi-directional buffer is instantiated, SLEW can be set within the design by assigning the SLEW parameter on the instantiated output buffer in the design.



**RECOMMENDED:** Use the instantiation template from the Language Templates or the *7 Series Libraries Guide for HDL Designs (UG768)* to specify the proper syntax.

The following example sets the slew rate on the OBUF instance named `fast_data_obuf` to **FAST**:

```
// OBUF: Single-ended Output Buffer
//      Virtex-7
// Xilinx HDL Language Template, version 2012.2

OBUF #(
  .DRIVE(12),      // Specify the output drive strength
  .IOSTANDARD("DEFAULT"), // Specify the output I/O standard
  .SLEW("FAST") // Specify the output slew rate
) fast_data_obuf (
  .O(FAST_DATA), // Buffer output (connect directly to top-level port)
  .I(fast_data_int) // Buffer input
);

// End of fast_data_obuf instantiation
```

## VHDL Syntax

When inferring I/O buffers, the SLEW attribute can be set in the design using the proper VHDL attribute syntax placed before the top-level output port declaration.

Declare the VHDL attribute as follows:

```
attribute SLEW : string;
```

Specify the VHDL attribute as follows:

```
attribute SLEW of port_name : signal is value;
```

*Where*

- `port_name` is a top-level output port in the design.

## VHDL Syntax Example

```
FAST_DATA : out std_logic;
attribute SLEW : string;
-- Sets the Slew rate to be FAST
attribute SLEW of STATUS : signal is "FAST";
```

## Alternative VHDL Syntax Example

If the output or bi-directional buffer is instantiated, SLEW can be set within the design by assigning the SLEW generic on the instantiated output buffer in the design.



**RECOMMENDED:** Use the instantiation template from the Language Templates or the *7 Series Libraries Guide for HDL Designs (UG768)* to specify the proper syntax.

The following example sets the slew rate on the OBUF instance named `fast_data_obuf` to `FAST`.

```
-- OBUF: Single-ended Output Buffer
--      Virtex-7
-- Xilinx HDL Language Template, version 2012.2

Fast_data_obuf : OBUF
generic map (
  DRIVE => 12,
  IOSTANDARD => "DEFAULT",
  SLEW => "FAST")
port map (
  O => FAST_DATA, -- Buffer output (connect directly to top-level port)
  I => fast_data_int -- Buffer input
);

-- End of fast_data_obuf instantiation
```

## XDC Syntax

```
set_property SLEW value [get_ports port_name]
```

*Where*

- `port_name` is an output or bi-directional port in the design.

## XDC Syntax Example

```
# Sets the Slew rate to be FAST
set_property SLEW FAST [get_ports FAST_DATA]
```

**Note** When this property is set in both HDL code and in XDC, the XDC property takes precedence.

## Affected Steps in the Design

- I/O Planning
- Report Noise
- Report Power

## See Also

*7 Series Libraries Guide for HDL Designs (UG768)*

- OBUF
- OBUFT
- IOBUF
- IOBUF\_DCIEN
- IOBUF\_INTERM\_DISABLE

---

## VCCAUX\_IO

VCCAUXIO specifies the operating voltage of the VCCAUX\_IO rail for a given I/O.

### Architecture Support

All architectures on High Performance (HP) bank I/O only

### Applicable Elements

- Ports (get\_ports)
- Cells (get\_cells)
- I/O buffers

### Values

- DONTCARE (default)
- NORMAL
- HIGH

### Syntax and Syntax Examples



**IMPORTANT:** Before copying syntax or coding examples from this PDF document for insertion into your code, see [Copying Syntax and Coding Examples from PDF Documents](#) in the Introduction to this guide.

---

#### Verilog Syntax

The VCCAUX\_IO attribute can be set in the design using the proper Verilog attribute syntax placed before the top-level output port declaration:

```
(* VCCAUXIO = "{DONTCARE|NORMAL|HIGH}" *)
```

#### Verilog Syntax Example

```
// Specifies a "HIGH" voltage for the VCCAUX_IO rail connected to this I/O  
(* VCCAUX_IO = "HIGH" *) input ACT3,
```

#### VHDL Syntax

The VCCAUX\_IO attribute can be set in the design using the proper VHDL attribute syntax placed before the top-level output port declaration.

Declare the VHDL attribute as follows:

```
attribute VCCAUX_IO : string;
```

© Copyright 2012 Xilinx

Specify the VHDL attribute as follows:

```
attribute VCCAUX_IO of port_name : signal is value;
```

*Where*

- `port_name` is a top-level port in the design.

#### VHDL Syntax Example

```
ACT3 : in std_logic;  
attribute VCCAUX_IO : string;  
-- Specifies a "HIGH" voltage for the VCCAUX_IO rail connected to this I/O  
attribute VCCAUX_IO of ACT3 : signal is "HIGH";
```

#### XDC Syntax

```
set_property VCCAUX_IO value [get_ports port_name]
```

*Where*

- `port_name` is a top-level port in the design.

#### XDC Syntax Example

```
# Specifies a "HIGH" voltage for the VCCAUX_IO rail connected to this I/O  
set_property VCCAUX_IO HIGH [get_ports ACT3]
```

**Note** When this property is set in both HDL code and in XDC, the XDC property takes precedence.

#### Affected Steps in the Design

- I/O Planning
- `place_design`
- Report Power



## Additional Resources

---

### Xilinx Resources

For support resources such as Answers, Documentation, Downloads, and Forums, see the Xilinx<sup>®</sup> Support website at:

[www.xilinx.com/support](http://www.xilinx.com/support)

For a glossary of technical terms used in Xilinx documentation, see:

[www.xilinx.com/company/terms.htm](http://www.xilinx.com/company/terms.htm)

---

### Solution Centers

See the [Xilinx Solution Centers](#) for support on devices, software tools, and intellectual property at all stages of the design cycle. Topics include design assistance, advisories, and troubleshooting tips.

---

### References

These documents provide supplemental material useful with this guide:

Vivado Design Suite 2012.2 Documentation,

[www.xilinx.com/support/documentation/dt\\_vivado\\_vivado2012-2.htm](http://www.xilinx.com/support/documentation/dt_vivado_vivado2012-2.htm)