

LogiCORE IP Gamma Correction v3.0 Bit Accurate C Model

User Guide

UG829 June 5, 2011



Xilinx is providing this product documentation, hereinafter “Information,” to you “AS IS” with no warranty of any kind, express or implied. Xilinx makes no representation that the Information, or any particular implementation thereof, is free from any claims of infringement. You are responsible for obtaining any rights you may require for any implementation based on the Information. All specifications are subject to change without notice.

XILINX EXPRESSLY DISCLAIMS ANY WARRANTY WHATSOEVER WITH RESPECT TO THE ADEQUACY OF THE INFORMATION OR ANY IMPLEMENTATION BASED THEREON, INCLUDING BUT NOT LIMITED TO ANY WARRANTIES OR REPRESENTATIONS THAT THIS IMPLEMENTATION IS FREE FROM CLAIMS OF INFRINGEMENT AND ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

Except as stated herein, none of the Information may be copied, reproduced, distributed, republished, downloaded, displayed, posted, or transmitted in any form or by any means including, but not limited to, electronic, mechanical, photocopying, recording, or otherwise, without the prior written consent of Xilinx.

© 2011 Xilinx, Inc. XILINX, the Xilinx logo, Artix, ISE, Kintex, Spartan, Virtex, and other designated brands included herein are trademarks of Xilinx in the United States and other countries. All other trademarks are the property of their respective owners.

Revision History

The following table shows the revision history for this document.

Date	Version	Revision
06/05/11	1.0	Initial Xilinx release.

Table of Contents

Revision History	2
Chapter 1: Introduction	
Features.....	5
Overview	5
Technical Support.....	6
Feedback.....	6
Chapter 2: User Instructions	
Unpacking and Model Contents	7
Installation	8
Software Requirements	8
Chapter 3: Using the C Model	
Gamma Correction Input and Output Video Structure	11
Initializing the Gamma Correction Input Video Structure.....	12
Chapter 4: C Model Example Code	
Compiling Gamma Correction C Model with Example Wrapper.....	15
Appendix A: Additional Resources	
Xilinx Resources	17
Core Resources.....	17

Introduction

This document introduces the bit accurate C model for the Xilinx® LogiCORE™ IP Gamma Correction v3.0 core, which has been developed primarily for system modeling.

Features

- Bit accurate with the Gamma Correction v3.0 core
- Statically linked library (.lib, .o, .obj – Windows)
- Dynamically linked library (.so – Linux)
- Available for 32-bit Windows and 64-bit Linux platforms
- Supports all features of the Gamma Correction core that affect numerical results
- Designed for rapid integration into a larger system model
- Example C code is provided to show how to use the function
 - Example application C code wrapper file supports 8-bit BMP only

Overview

The Xilinx LogiCORE IP Gamma Correction v3.0 has a bit accurate C model for 32-bit Windows and 64-bit Linux platforms. The model has an interface consisting of a set of C functions, which reside in a statically link library (shared library). Full details of the interface are given in [Chapter 3, Using the C Model](#). An example piece of C code is provided to show how to call the model.

The model is bit accurate, as it produces exactly the same output data as the core on a frame-by-frame basis. However, the model is not cycle accurate, as it does not model the core's latency or its interface signals.

The latest version of the model is available for download on the Xilinx™ LogiCORE IP Gamma Correction web page at:

<http://www.xilinx.com/products/intellectual-property/EF-DI-GAMMA.htm>

Technical Support

For technical support, go to www.xilinx.com/support. Questions are routed to a team with expertise using the Gamma Correction v3.0 core.

Xilinx provides technical support for use of this product as described in this user guide (*LogiCORE IP Gamma Correction Bit Accurate C Model User Guide*).

Xilinx cannot guarantee functionality or support of this product for designs that do not follow these guidelines.

Feedback

Xilinx welcomes comments and suggestions about the Gamma Correction v3.0 core and the accompanying documentation.

Gamma Correction v3.0 Bit Accurate C Model and IP Core

For comments or suggestions about the Gamma Correction v3.0 core and bit accurate C model, submit a WebCase from:

<http://www.xilinx.com/support/clearxpress/websupport.htm>

Be sure to include this information:

- Product name
- Core version number
- Explanation of your comments

Document

For comments or suggestions about the documentation for the Gamma Correction v3.0 core and bit accurate C model, submit a WebCase from:

<http://www.xilinx.com/support/clearxpress/websupport.htm>

Be sure to include this information:

- Document title
- Document number
- Page number(s) to which your comments refer
- Explanation of your comments

User Instructions

Unpacking and Model Contents

Unzip the `v_gamma_v3_0_bitacc_model.zip` file, containing the bit accurate models for the Gamma Correction IP Core. This creates the directory structure and files in [Table 2-1](#).

Table 2-1: Directory Structure and Files of the Gamma Correction v3.0 Bit Accurate C Model

File Name	Contents
README.txt	Release notes
ug829_v_gamma.pdf	LogiCORE IP Gamma Correction Bit Accurate C Model User Guide
v_gamma_v3_0_bitacc_cmodel.h	Model header file
rgb_utils.h	Header file declaring the RGB image/video container type and support functions
bmp_utils.h	Header file declaring the bitmap (.bmp) image file I/O functions
video_utils.h	Header file declaring the generalized image/video container type, I/O and support functions
run_bitacc_cmodel.c	Example code calling the C model
kodim19_128x192.bmp	128x192 sample test image of the lighthouse image from the True Color Kodak test images
/lin64	Precompiled bit accurate ANSI C reference model for simulation on 64-bit Linux platforms
libIp_v_gamma_v3_0_bitacc_cmodel.so	Model shared object library
libstlport.so.5.1	STL library, referenced by <code>libIp_v_gamma_v3_0_bitacc_cmodel.so</code>
/win32	Precompiled bit accurate ANSI C reference model for simulation on 32-bit Windows platforms.
libIp_v_gamma_v3_0_bitacc_cmodel.lib	Precompiled library file for win32 compilation

Installation

For Linux, make sure these files are in a directory that is in your `$LD_LIBRARY_PATH` environment variable:

- `libIp_v_gamma_v3_0_bitacc_cmodel.so`
- `libstlport.so.5.1`

Software Requirements

The Gamma Correction v3.0 C models were compiled and tested with the software listed in [Table 2-2](#).

Table 2-2: Compilation Tools for the Bit Accurate C Models

Platform	C Compiler
64-bit Linux	GCC 4.1.1
32-bit Windows	Microsoft Visual Studio 2005

Using the C Model

The bit accurate C model is accessed through a set of functions and data structures that are declared in the `v_gamma_v3_0_bitacc_cmodel.h` file.

Before using the model, the structures holding the inputs, generics and output of the Gamma Correction instance must be defined:

```

struct xilinx_ip_v_gamma_v3_0_generics gamma_generics;
struct xilinx_ip_v_gamma_v3_0_inputs  gamma_inputs;
struct xilinx_ip_v_gamma_v3_0_outputs gamma_outputs;

```

The declaration of these structures is in the `v_gamma_v3_0_bitacc_cmodel.h` file.

[Table 3-1](#) lists the generic parameters taken by the Gamma Correction v3.0 IP core bit accurate model, as well as the default values. For an actual instance of the core, these parameters can only be set in generation time through the CORE Generator™ GUI.

Table 3-1: Model Generic Parameters and Default Values

Generic variable	Type	Default Value	Range	Description
IWIDTH	int	8	8,10,12	Input data width.
OWIDTH	int	8	8,10,12	Output width.
INTPOL	int	0	0, 1	1 indicates that the core uses interpolation. ¹ Enabled only when IWIDTH = 12.
IDENTICAL_TABLES	int	1	0,1	1 indicates that the core uses interpolation. ¹ Enabled only when IWIDTH = 8 or 10.
DEFAULT_GAMMA	double	0.45	0.1 – 10.0	Gamma value used to initialize the Gamma correction tables. Initialization applies to all core interface options.

¹ For a detailed description of inputs and other generic parameters, see the *LogiCORE IP Gamma Correction Data Sheet (DS719)*.

Calling `xilinx_ip_v_gamma_v3_0_get_default_generics(&gamma_generics)` initializes the generics structure with the Gamma GUI defaults, listed in [Table 3-1](#).

Table 3-2: Core Generic Parameters and Default Values

Input Variable	Type	Default Value	Range	Description
video_in	video_struct	Null	N/A	Container to hold input image or video data. ²
RTABLE	uint16[4096]	$\text{round}\left(255 \frac{k^{0.45}}{255^{0.45}}\right)$	0 to $2^{OWIDTH} - 1 - 1$	The R-, G-, and BTABLE variables hold the Gamma correction tables for the color channels. ¹
GTABLE	uint16[4096]			
BTABLE	uint16[4096]			

¹ For a detailed description of inputs and other generic parameters, see the *LogiCORE IP Gamma Correction Data Sheet* (DS719).

² For the description of the input structure, see [Initializing the Gamma Correction Input Video Structure](#).

The structure `gamma_inputs` defines the values of run time parameters and the actual input image. The Red, Green, and Blue tables can be set dynamically through the pCore and General Purpose Processor interfaces. Consequently, these values are passed as inputs to the core, along with the actual test image, or video sequence (see [Table 3-2](#)).

Calling `xilinx_ip_v_gamma_v3_0_get_default_inputs(&gamma_generics, &gamma_inputs)` initializes members of the input structure default values (see [Table 3-2](#)).

Note: The `video_in` variable is not initialized because the initialization depends on the actual test image to be simulated. [Chapter 4, C Model Example Code](#) describes the initialization of the `video_in` structure.

After the inputs are defined, the model can be simulated by calling this function:

```
int xilinx_ip_v_gamma_v3_0_bitacc_simulate(
    struct xilinx_ip_v_gamma_v3_0_generics* generics,
    struct xilinx_ip_v_gamma_v3_0_inputs* inputs,
    struct xilinx_ip_v_gamma_v3_0_outputs* outputs).
```

Results are included in the outputs structure, which contains only one member, type `video_struct`. After the outputs are evaluated and saved, dynamically allocated memory for input and output video structures must be released by calling this function:

```
void xilinx_ip_v_gamma_v3_0_destroy(
    struct xilinx_ip_v_gamma_v3_0_inputs *input,
    struct xilinx_ip_v_gamma_v3_0_outputs *output).
```

Successful execution of all provided functions, except for the destroy function, return value 0. A non-zero error code indicates that problems occurred during function calls.

Gamma Correction Input and Output Video Structure

Input images or video streams can be provided to the Gamma Correction v3.0 reference model using the `video_struct` structure, defined in `video_utils.h`:

```

struct video_struct{
    int          frames, rows, cols, bits_per_component, mode;
    uint16***   data[5]; };
    
```

Table 3-3: Member Variables of the Video Structure

Member Variable	Designation
frames	Number of video/image frames in the data structure.
rows	Number of rows per frame. Pertaining to the image plane with the most rows and columns, such as the luminance channel for YUV data. Frame dimensions are assumed constant through all frames of the video stream. However different planes, such as y, u and v can have different dimensions.
cols	Number of columns per frame. Pertaining to the image plane with the most rows and columns, such as the luminance channel for YUV data. Frame dimensions are assumed constant through all frames of the video stream. However different planes, such as y, u and v can have different dimensions.
bits_per_component	Number of bits per color channel/component. All image planes are assumed to have the same color/component representation. Maximum number of bits per component is 16.
mode	Contains information about the designation of data planes. Named constants to be assigned to mode are listed in Table 3-4 .
data	Set of five pointers to three dimensional arrays containing data for image planes. Data is in 16-bit unsigned integer format accessed as <code>data[plane][frame][row][col]</code> .

Table 3-4: Named Constants for Video Modes with Corresponding Planes and Representations

Mode	Planes	Video Representation
FORMAT_MONO	1	Monochrome – Luminance only
FORMAT_RGB	3	RGB image/video data
FORMAT_C444	3	444 YUV, or YCrCb image/video data
FORMAT_C422	3	422 format YUV video, (u, v chrominance channels horizontally sub-sampled)
FORMAT_C420	3	420 format YUV video, (u, v sub-sampled both horizontally and vertically)
FORMAT_MONO_M	3	Monochrome (Luminance) video with Motion
FORMAT_RGBA	4	RGB image/video data with alpha (transparency) channel
FORMAT_C420_M	5	420 YUV video with Motion
FORMAT_C422_M	5	422 YUV video with Motion
FORMAT_C444_M	5	444 YUV video with Motion
FORMAT_RGBM	5	RGB video with Motion

Initializing the Gamma Correction Input Video Structure

The easiest way to assign stimuli values to the input video structure is to initialize it with an image or video. The `bmp_util.h` and `video_util.h` header files packaged with the bit accurate C models contain functions to facilitate file I/O.

Bitmap Image Files

The header `bmp_utils.h` declares functions that help access files in Windows Bitmap format (http://en.wikipedia.org/wiki/BMP_file_format). However, this format limits color depth to a maximum of 8-bits per pixel, and operates on images with three planes (R,G,B). Consequently, the following functions operate on arguments type `rgb8_video_struct`, which is defined in `rgb_utils.h`. Also, both functions support only true-color, non-indexed formats with 24-bits per pixel.

```
int write_bmp(FILE *outfile, struct rgb8_video_struct *rgb8_video);
int read_bmp(FILE *infile, struct rgb8_video_struct *rgb8_video);
```

Exchanging data between `rgb8_video_struct` and general `video_struct` type frames/videos is facilitated by these functions:

```
int copy_rgb8_to_video(struct rgb8_video_struct* rgb8_in,
                     struct video_struct* video_out );
int copy_video_to_rgb8(struct video_struct* video_in,
                     struct rgb8_video_struct* rgb8_out );
```

Note: All image/video manipulation utility functions expect both input and output structures initialized; for example, pointing to a structure that has been allocated in memory, either as static or dynamic variables. Moreover, the input structure must have the dynamically allocated container (data or r, g, b) structures already allocated and initialized with the input frame(s). If the output container structure is pre-allocated at the time of the function call, the utility functions verify and issue an error

if the output container size does not match the size of the expected output. If the output container structure is not pre-allocated, the utility functions create the appropriate container to hold results.

Binary Image/Video Files

The `video_utils.h` header file declares functions that help load and save generalized video files in raw, uncompressed format.

```
int read_video( FILE* infile,  struct video_struct* in_video);
int write_video(FILE* outfile, struct video_struct* out_video);
```

These functions serialize the `video_struct` structure. The corresponding file contains a small, plain text header defining, "Mode", "Frames", "Rows", "Columns", and "Bits per Pixel". The plain text header is followed by binary data, 16-bits per component in scan line continuous format. Subsequent frames contain as many component planes as defined by the video mode value selected. Also, the size (rows, columns) of component planes can differ within each frame as defined by the actual video mode selected.

Working with Video_struct Containers

The `video_utils.h` header file defines functions to simplify access to video data in `video_struct`.

```
int video_planes_per_mode(int mode);
int video_rows_per_plane(struct video_struct* video, int plane);
int video_cols_per_plane(struct video_struct* video, int plane);
```

The `video_planes_per_mode` function returns the number of component planes defined by the mode variable, as described in [Table 3-4](#). The `video_rows_per_plane` and `video_cols_per_plane` functions return the number of rows and columns in a given plane of the selected video structure. The following example demonstrates using these functions in conjunction to process all pixels within a video stream stored in the `in_video` variable:

```
for (int frame = 0; frame < in_video->frames; frame++) {
    for (int plane = 0; plane < video_planes_per_mode(in_video->mode); plane++) {
        for (int row = 0; row < rows_per_plane(in_video,plane); row++) {
            for (int col = 0; col < cols_per_plane(in_video,plane); col++) {
                // User defined pixel operations on
                // in_video->data[plane][frame][row][col]
            }
        }
    }
}
```


C Model Example Code

An example C file, `run_bitacc_cmodel.c`, is provided to demonstrate the steps required to run the model. After following the compilation instructions, run the example executable. The executable takes the path/name of the input file and the path/name of the output file as parameters. If invoked with insufficient parameters, this help message is issued:

```
Usage: run_bitacc_cmodel in_file out_file
in_file      : path/name of the input  BMP file
out_file     : path/name of the output BMP file
```

During successful execution, two files with a `.bin` extension are created. The first file corresponds to the input BMP image, with the same path and name as the input file, and a `.bin` extension. The other file similarly corresponds to the output file. These files contain the inputs and outputs of the Gamma Correction algorithm in full precision, as the BMP format does not support color resolutions beyond 8-bits per component. The structure of `.bin` files are described in [Binary Image/Video Files](#).

To ease modifying and debugging the provided top-level demonstrator using the built-in debugging environment of Visual Studio, the top-level command line parameters can be specified through the Project Property Pages using these steps:

1. In the Solution Explorer pane, right-click the project name and select Properties in the context menu.
2. Select Debugging on the left pane of the Property Pages dialog box.
3. Enter the paths and file names of the input and output images in the Command Arguments field.

Compiling Gamma Correction C Model with Example Wrapper

Linux (64-bit)

To compile the example code, perform these steps:

1. Set your `$LD_LIBRARY_PATH` environment variable to include the root directory where you unzipped the model zip file using a command such as:

```
setenv LD_LIBRARY_PATH <unzipped_c_model_dir>:${LD_LIBRARY_PATH}
```
2. Copy these files from the `/lin64` directory to the root directory:

```
libstlport.so.5.1
libIp_v_gamma_v3_0_bitacc_cmodel.so
```

3. In the root directory, compile using the GNU C Compiler with this command:

```
gcc -x c++ run_bitacc_cmodel.c -o run_bitacc_cmodel -L. -  
lIp_v_gamma_v3_0_bitacc_cmodel -Wl,-rpath,.
```

Windows (32-bit)

The precompiled library `v_gamma_v3_0_bitacc_cmodel.lib`, and top-level demonstration code `run_bitacc_cmodel.c` should be compiled with an ANSI C compliant compiler under Windows. An example procedure is provided here using Microsoft Visual Studio.

1. In Visual Studio, create a new, empty Win32 Console Application project.
2. As existing items, add:
 - a. `libIp_v_gamma_v3_0_bitacc_cmodel.lib` to the Resource Files folder of the project
 - b. `run_bitacc_cmodel.c` to the Source Files folder of the project
 - c. `v_gamma_v3_0_bitacc_cmodel.h` to the Header Files folder of the project
3. After the project is created and populated, it must be compiled and linked (built) to create a win32 executable. To perform the build step, select "Build Solution" from the Build menu. An executable matching the project name has been created either in the Debug or Release subdirectories under the project location based on whether "Debug" or "Release" has been selected in the "Configuration Manager" under the Build menu.

Additional Resources

Xilinx Resources

For support resources such as Answers, Documentation, Downloads, and Forums, see the Xilinx Support website at:

<http://www.xilinx.com/support>.

For a glossary of technical terms used in Xilinx documentation, see:

http://www.xilinx.com/support/documentation/sw_manuals/glossary.pdf.

Core Resources

For detailed information and updates about the Xilinx LogiCORE IP Gamma Correction v3.0 core, see:

<http://www.xilinx.com/products/intellectual-property/EF-DI-GAMMA.htm>

- *Gamma Correction v3.0 Data Sheet (DS719)*
- *Gamma Correction v3.0 Release Notes*

